

LAY DOWN 1 SIDE (THE TABS GO UP TO TOP)
INSERT SHELVES (HEAT TAPE NOTCH GOES TO BACK)
SET THE OTHER SIDE ON THE SHELVES
SCREW THE SIDE DOWN

ROLL RACK OVER
TO GET TO THE OTHER SIDE, SCREW THAT ONE ON
THEN ATTACH AND SCREW BACK

SLIDE HEAT TAPE DOWN FROM TOP INTO NOTCH

TAPE PROBE TO THE HEAT TAPE (DO NOT PUT PROBE INTO THE BOX !)

